



How to Program Your Polaris URC1090 Remote

1. Turn on your TV
2. Point the remote at the TV
3. Press the TV button and release
4. Press and hold the SETUP button until the TV button blinks twice, then release
5. Enter 9-9-1 (the TV button should blink twice)
6. Repeatedly press the CH+ key until your TV turns off. (Your TV should not change channels during this step. If it is, start over at step 3.)
7. Once your TV turns off press the SETUP button, then release it to lock the code for your device

If programming was successful, you should then be able to adjust the volume with this remote. If you aren't able to do so, repeat all steps again. If you are still having trouble or need assistance, please contact our office.



(507) 886-6422

support@mibroadband.com